

## OPERATING INSTRUCTIONS

1. Connect tester to shop air (between 75-175 psi).
2. Turn control knob to **TEST**.
3. Connect pressure supply hose to system being tested.
4. Once flow meter ball stops descending, leak size will be indicated.
5. For pressure decay, turn control knob to **DECAY/OFF** and view gauge.

**NOTE:** Moisture may occasionally be present at the drain port on the bottom of the LPLT-100. This is a normal operation of the internal self-draining air & moisture filter.