







Part #	Photo	Description
941962		12mm BMW / Jaguar / Mercedes
941963		10mm BMW / Jaguar / Mercedes
941964		15mm Volvo V70 / 850AWD
941965		13.5mm Volvo S Series Push Lok
941979		12mm Volkswagen Passat
942029		M18 x 1.5 Cadillac Dipstick Adapter
40100018		Lexus / Toyota
40100019		Ford 6R / GM Colorado Sealed Transmission Adapter <i>Used with Y-Adapter included with machine</i>
941927		Land Rover
941928		
40100035 (Complete)		Ford Transit Connect, 250 & 350
40100053 (Adapter)		

Part #	Photo	Description
40100038		Chevy Full Size Chevy Colorado (2015+)
40100039		Ford Explorer, Taurus, Escape, Flex, & Edge
40200276		Mercedes
40200275		
40100049 (Complete)		Mercedes 230 Series
40300286 (Adapter)		
40100075		Buick Envision & Enclave (2016-17) Chevy Equinox (2013-17)
40100081		Audi Q5 (2016-17)
40100085		Range Rover (All) BMW X3 (2012)
40100080		Works in place of open-end hose (#55) when using 942163S GM Adapter
40100082		Dodge 4WD Works in place of open-end hose (#59) when using 940328, 941923, or 942169 1/2" adapters
40100083		1/8" NPT Transmission Drain Plug Adapter Ford Explorer (2012+)

Part #	Photo	Description
40200865		Toyota/Lexus Metric Step Adapter Kit
40200883		Step adapter also works with open-end hoses #55 & #81
40200680		"TE" Adapter Replaces open-end hose #55 when using 3/8" adapters (941925, 940329, and 941910)
40200681		"TD" Adapter Replaces open-end hose #63 when using 5/16" adapter (940334)
40100084		Chevy Duramax female adapter for vehicles with Allison transmission 6.0L V8 and larger Works in place of open-end hose (#149) when using 941899 5/8" adapter
40100089		Dodge / Ford Female Thermostat Bypass Fitting