



Non By-Pass Filters for Heated Cooler Line Flusher



Changing the filters is what keeps your Flusher working.

If you estimate that one vehicle takes about 35 minutes of actual flushing time, you should change your filters about every 100 flushes - or every 60 hours. Once a month is an easy way to remember how often you should change your filters.



2 NBP Spin On
Filters per flusher

Available individually or by the case of 12



Domestic Adapters (TTCF-DA)

- D1 - Universal 1/2" Female
- D2 - Universal 3/8" Female
- D3 - Universal 5/16" Male
- D4 - GM/Ford/Toyota (13 mm) 5/16" Female Threaded
- D5 - GM/Toyota/Dodge/Chrysler (15mm) 3/8" Female Threaded
- D6 - Dodge/Chrysler 5/16" Male Threaded
- D7 - Dodge/Chrysler 3/8" Male Threaded

Banjo Adapters (TTCF-BA)

- B1 - 12 mm Fittings for Banjo-Style Cooler Lines
- B2 - 14 mm Fittings for Banjo-Style Cooler Lines

Early Super Duty Adapters (TTCF-SDA)

- S1 - Universal 1/2" Male Ford/Dodge/ Chrysler/GM
- S2 - 1/2" Hose Clamps
- S3 - 1/2" Female Ford/Dodge/Jaguar/Early Super Duty/Allison
- S4 - 1/2" Male Ford/Dodge 518/47RE/48RE
- S5 - Universal Allison/Ford/Dodge Truck with Steel Lines

Honda Adapters (TTCF-HA)

- H1 - Honda Banjo Fitting (used with Honda Transmission Cooler Bolt)
- H2 - Honda Transmission Flexible Cooler Line Push In Fitting
- H3 - Honda Universal Transmission Cooler Line for Steel Lines

Push On Adapters (TTCF-POA)

- P1 - 9 mm Corvette/Hummer/GM 6-Speed Push On
- P2 - 11 mm Dodge/Chrysler/TF Early Push On
- P3 - 16 mm (was 17 mm) Ford 500/Taurus/AWF21-B Push On
- P4 - 19 mm Ford Late Model Navigator/Explorer/F-150/F-250 and these new transmissions: 6R140/6R80/6R60/6R75/6HP26

Toyota/Lexus Adapters (P5 Series)

- TTCF-P5** - A760 (2007 GS350 ALL) A760H (2006 IS250 AWD, 2006 GS300 AWD, 2007/8 GS350 AWD) A760E (2006 IS350, 2007/8 GS350)
- TTCF-P5A** - AB60E/F (2007 Tundra, 2008 Sequoia) AB60F (2008 Land Cruiser, 2008 LX570)
- TTCF-P5B** - A960E (2006 IS250, 2006 GS300)
- TTCF-P5C** - A750E/F (2007/9 Tundra, 2008 Sequoia)
- TTCF-P5D** - A760E/F (2010 Tundra, 2010 Sequoia) A760F (2010 GX460)

Honda/Acura Adapter (TTCF-P6)

- P6 - Acura (TL) & Accord (A/T)

Audi/VW/Nissan Adapter (TTCF-AVWN)

- AVWN - Audi MU4; VW 01M, 01P, & 01N; Nissan KTM, KT4

Round VW Adapter (TTCF-RVW)

- RVW - Primarily Volkswagen (e.g. JF56E & 09M) but also used for some Jaguar, Land Rover, and Mazda applications

*These are the applications that we KNOW these adapters fit. There may be more. If the adapter you are attempting to use fits securely and tightly without any leaks, then feel free to use that fitting. And if you let us know any new applications for these adapters that you've discovered, we'll credit you on our website!